


WHAT'S INCLUDED:




FLEX System



Power Cord



Wi-Fi Antenna



YOU ALSO NEED THE FOLLOWING (NOT INCLUDED IN THE KIT):

- Monitor
- HDMI cable
- Keyboard
- Mouse
- Ethernet cable (optional)

WHAT'S INSTALLED:

- Intel® Media SDK
- Intel® Distribution of OpenVINO™ Toolkit

LEARN MORE ABOUT THE KIT AND GET STARTED

<https://www.ieiworld.com/flex-bx200-aiot-development-kit>



<https://software.intel.com/en-us/iot/9th-gen-core-dev-kit>



Copyright© 2020 IEI. All rights reserved. Specifications are subject to change without notice. Intel® and the Intel logo are trademarks of Intel® Corporation or its subsidiaries in the U.S. and/or other countries. Other brands and product names are trademarks or registered trademarks of their respective holder.

FLEX Accelerate to the Future

IEI FLEX AIoT Developer Kit Quick Start Guide



1 Connect your system using Ethernet or Wi-Fi

The FLEX system is equipped with Ethernet and Wi-Fi capabilities.


Connect using Ethernet

Plug the Ethernet cable into your system, and then plug the other end of the cable into the router.


OR

Connect using Wi-Fi

To install the Wi-Fi antenna, screw each antenna onto the gold knobs on the back of the FLEX system. To begin using the internet, connect to your wireless network and select the desired SSID.



3 Plug in all cords



Keyboard



Mouse

4 Turn on

Until the LED lights up in blue 



Turn on

5 Log in

Log in with the default user name and password.

Username:

Password:

6 Continue here:

<https://software.intel.com/en-us/iot/9th-gen-core-dev-kit>

